RNA-seq解析パイプライン: *de novo*

Shuji Shigenobu 重信 秀治

基礎生物学研究所 生物機能解析センター



de novo RNA-seq


Millions of short reads pre-processing mapping Reads aligned to reference summarization by unit (gene, transcript, exon) Table of counts normalization DE testing List of DE gene systems biology GO enrichment

multivariate analysis network analysis

Biological insights

- I. Build reference
- 2. Characterize reference


RNA-seq analysis pipeline (de novo strategy)




de novo assemblers of RNA-seq

De novo assemblers use reads to assemble transcripts directly, which does not depend on a reference gnome.

- Trinity
- Oases
- TransAbyss
- ▶ EBARDenovo
- **...**



https://github.com/trinityrnaseq/trinityrnaseq/wiki



Trinity example

- Input: Illumina short reads in FASTQ | FASTA format
- Output: assembled contigs in FASTA format

(Trinity is supported on only Linux)

DEG analysis

▶ Follow transcript-based RNA-seq pipeline

Advanced

Clean up reference sequences

- An issue: Inflation of the number of Trinity contigs is often observed.
 - ▶ Trinity outputs splicing variants separately
 - Contaminations
 - Artifacts (bad contigs)
 - Incomplete contigs with very low expression.
- Solution
 - Filter out unwanted contigs.
 - Filter out very lowly expressed transcripts.
 - ▶ Cluster similar sequences.

Remove redundancy in reference sequences

Strategy and Tools

- Choose one representative transcript from each cluster based on Trinity component information. (longest or highest expression)
- Clustering
 - ► CDHIT-EST (http://weizhongli-lab.org/cd-hit/)
 - ▶ Corset (Davidson et al., 2014).
 - ▶ RapClust (https://github.com/COMBINE-lab/RapClust)
 - EvidentialGene (http://arthropods.eugenes.org/EvidentialGene/trassembly.html)


Advantage of redundancy reduction

- ▶ Gene-oriented analysis => easier interpretation
- ▶ Better control of multiple comparison.


PacBio Iso-Seq for building transcriptome catalogues

Advanced

Experimental Pipeline



SampleNet: Iso-Seq Method with Clonetech® cDNA Synthesis Kit



Informatics Pipeline

